

Montagehandleiding / Instructions de montage
 Montagehinweis / Mounting instructions



OPTIE_OPTION
 VENTIELEN_VANNES_VENTILE_VALVES




+



* Niet mogelijk met ventiel 5094.402
 * Pas possible avec vanne 5094.402
 * Nicht möglich mit Ventil 5094.402
 * Not possible with valve 5094.402

AFMETINGEN_DIMENSIONS_ABMESSUNGEN_DIMENSIONS












DIMENSIONS in cm		
D	d	h min*
11.9	5.2	10
16.9	7.7	12

Code	X	Y
5094.4414	1.2	3.8
5090.405	2.7	5
5090.407	2.7	5
5090.13001	2.2	5.5

- * Kleinere afstanden kunnen een lichte daling van de afgifte tot gevolg hebben.
- * Des dimensions inférieures peuvent diminuer légèrement l'émission de chaleur.
- * Kleinere Abstände verändern geringfügig die Wärmeleistung.
- * Smaller dimensions can decrease output.





This paper environmentally friendly so is not bleached and 100% recycled